

IMPORTANT SAFETY NOTICE

ADALIT RECHARGEABLE TORCHES
MODELS L.3000 AND L.3000POWER

Measure to be Taken: Replacement of battery.

Date: 6 August 2018.

To the attention of: Distributors and Customers.



Description of the Problem:

We have discovered that some Adalit L.3000 and L.3000Power torches sold between January of 2016 and June of 2017 have experienced battery failure.

Because of this failure, their use during the recharging process could result in safety problems due to overheating of the battery.

Corrective Measures:

If you have acquired one of these torches between the dates indicated above, and your torch has been affected by this problem, remove the torch from the charger and DO NOT charge it again until you have received the new battery and used it to replace the old battery.

Battery Replacement Instructions:

If you have acquired an Adalit L.3000 or L.3000Power torch, check its serial number, which you will find on a label located on the bottom of the torch.

The serial numbers affected range from 060533 to 097388 for the Adalit L.3000 model, and from 000301 to 007031 for the L.3000Power model, which were sold in Germany and Austria between the dates indicated above. Not all the torches with serial numbers falling within the above-mentioned ranges are affected.

On our website www.recalladalit.com you can verify whether the serial number of your torch is among those affected, and you can fill out a form in order to receive your new battery, free. To acquire the new battery, it is necessary to follow the instructions on our website.

In addition, we have created a Call Center for the German Market available Monday to Friday, from 8 am to 5 pm, to take all phone calls.

To whom is this notice to be sent:

This notice shall be distributed to all persons responsible for managing this type of information within their own organization, and to any other organization to which the affected equipment may have been distributed.

Please distribute this notice to other organizations that may be affected by this measure.

Please keep this notice, and any and all measures resulting from said notice, in mind during the period of time necessary to ensure that the corrective measure is effective.

In case of any doubts, please do not hesitate to contact us at our website www.recalladalit.com

Thank you very much for your help. We apologize for any inconvenience this may have caused.

Adaro Tecnología S.A.

Jimena Fernandez de la Vega Nº 38

33203 Gijón Asturias

www.recalladalit.com